


FIG.15 FUEL TANK - SEAT



RL250

FIG.15 FUEL TANK - SEAT

| Ref.No. | Part No.        | Description             | Q'ty |   | Remarks                                                    |
|---------|-----------------|-------------------------|------|---|------------------------------------------------------------|
|         |                 |                         | L    | M |                                                            |
| 1-1     | 44110-38000-714 | TANK, fuel              | 1    | - | Material:Aluminium<br>to 44110-38001-714<br>Material:Steel |
| 1-2     | 44110-38001-714 | TANK, fuel              | 1    | - |                                                            |
| 1-3     | 44110-38001-997 | TANK, fuel              | -    | 1 |                                                            |
| 2       | 68111-38000-719 | EMBLEM, fuel tank       | 2    | - |                                                            |
| 3       | 68111-38600-998 | EMBLEM, fuel tank       | -    | 2 |                                                            |
| 4       | 68115-38000-064 | TAPE, striping          | 2    | 2 |                                                            |
| 5       | 44200-28300     | CAP ASSY, fuel tank     | 1    | 1 |                                                            |
| 6       | 44248-28300     | GASKET, fuel tank cap   | 1    | 1 |                                                            |
| 7       | 09343-05076     | HOSE, breather          | 1    | 1 |                                                            |
| 8-1     | 44300-05110     | COCK ASSY, fuel         | 1    | - | to 44300-05111                                             |
| 8-2     | 44300-05111     | COCK ASSY, fuel         | -    | 1 |                                                            |
| 9       | 44300-01882     | FILTER SET              | 1    | 1 |                                                            |
| 10      | 44344-05110     | NET, filter             | 1    | 1 |                                                            |
| 11      | 44346-05110     | GASKET, cup             | 1    | 1 |                                                            |
| 12      | 09343-05036     | HOSE                    | 1    | 1 | L:150                                                      |
| 13      | 09401-08401     | CLIP                    | 2    | 2 |                                                            |
| 14      | 09329-10007     | CUSHION                 | 2    | 2 |                                                            |
| 15      | 44541-30000     | CUSHION, fuel tank rear | 1    | 1 |                                                            |
| 16      | 44549-30000     | PLATE, rear cushion     | 2    | 2 |                                                            |
| 17      | 09320-12013     | CUSHION                 | 1    | 1 |                                                            |
| 18      | 01122-08408     | BOLT                    | 1    | 1 |                                                            |
| 19      | 09160-08025     | WASHER                  | 1    | 1 |                                                            |
| 20      | 09180-08045     | SPACER                  | 1    | 1 |                                                            |
| 21      | 08321-21088     | LOCK WASHER             | 1    | 1 |                                                            |
| 22      | 01112-06508     | BOLT                    | 1    | 1 |                                                            |

RL250

0811A

