


FIG.18 HANDLE SWITCH



RL250

FIG.18 HANDLE SWITCH

Ref.No.	Part No.	Description	Q'ty		Remarks
			L	M	
1	57100-26110	GRIP ASSY, throttle	1	1	
2	02112-05168	•SCREW	2	2	
3	57110-26110	•GRIP, throttle	1	1	
4	57211-25700	GRIP, LH	1	1	
5	57300-11011	LEVER ASSY, brake	1	1	
6	57420-18011	•LEVER	1	1	
7	57431-11010	•BOLT	1	1	
8	08321-21068	•LOCK WASHER	1	1	
9	57433-11010	•NUT	1	1	
10	04111-16158	•COTTER PIN	1	1	
11	57441-11010	•ADJUSTER, cable	1	1	
12	57442-11010	•NUT	1	1	
13	02112-06208	•SCREW	1	1	
14	57500-11011	LEVER ASSY, clutch	1	1	
15	57620-31010	•LEVER	1	1	
16	57431-11010	•BOLT	1	1	
17	08321-21068	•LOCK WASHER	1	1	
18	57433-11010	•NUT	1	1	
19	04111-16158	•COTTER PIN	1	1	
20	57441-11010	•ADJUSTER, cable	1	1	
21	57442-11010	•NUT	1	1	
22-1	57451-11010	•SCREW	1	-	to 01112-06208
22-2	01112-06208	•BOLT	-	1	

RL250